



Installation of KONNY pistons to the KONNY 500cc engines

KONNY 500 engine have two type of pistons.
Both types have same dimension but have
another pins position for ring lock and bottom slots
are different too. You must fit pistons to crankshaft
by sketch below.

Pistons with mark No. 2 must be fitted to inside cylinders.
Pistons with mark No. 1 must be fitted to outside cylinders.
Pins must drift to the inlet ports.

VIEW FROM TOP

